

4 load cells scale



FEATURES:

Supplied in pairs.

- · Weighing bars in painted steel.
- · Fixed feet base on ZFI802 model / Swing feet base on ZFI1251 model.
- · ABS indicator, model BR15.
- · Backlight LCD display with six 30 mm height digits.
- Backlight of the display with 3 types: automatic, activated and deactivated.
- IP54 protection.
- · Waterproof keyboard with 5 function keys and ON/OFF keys.
- · Keyboard functions: Unit selector, zero, tare, accumulation and manual data transfer to PC or printer.
- Rechargeable internal battery 6V/4Ah.

- Operating temperature range: -10°C + 40°C.
 Unique range / multi-range / multi-interval.
 Power supply with adaptor AC/DC 240Vac 50Hz.
 Unit 1 to choose: off, kg, t and g; Unit 2 to choose: off, lb, lboz; Unit 3 to choose: off, Taiwan Jin, CA or VISS.
- · RS232 output PC and print formats.
- Auto switch off (programmable: from 1 to 99 minutes).
- · 2 meters of cable for each weighing bar with a single connector.

FUNCTIONS:

- Accumulation
- Totalization
- · Piece counting
- Zero
- Hold (4 modes: deactivate, filter for animals, peak value, stable weight and stable weight with auto cancel in zero)
- Checkweighing function visual and alarm signals
- Three speeds of AD converter (high, medium and low)
- · Programmable gravity
- · Gross/Net
- Tare







Metric opening to fix upper chassis in plate



Floor fitting by anchoring bolts (Non Included)



Swing feet base on 260625 model

						 Certifications	
Code #	Capacity	Readout	Dimensions	Packing	Packing	ENAC	
	(kg)	(g)	(mm)	dimensions (mm)	weight (kg)	Code #	
260626	2000	500	800x105	890x340x170+330x250x220	26+3,2	900004	
260625	3000	1000	1250x100	1400x340x170+330x250x220	32+3,2	900004	

*See optional indicator BR15